



40KVA ONLINE UPS

PS-POU40KT3#32BC0KR

USER MANUAL



Foreword

Y greqo g" vq" wug" qwt" r tqf wev." r rgcug" tgc f " vj ku" o cpwcn' vj qtqwi j n(0' K' kpenwf gu" kputwev kqpu"qh'uchgv{ "kpuvcmev kqp"cpf "qr gtcv kqp"cdqw'vj tgg/r j cug"kp"cpf "vj tgg/r j cug"qw" WRU' ku" kpuvcmev kqp" cpf " o ckpgpcpeg" o wuv" dg" r gthqto gf " d{ " s wcnk hgf " gpi kpggt" cwj qtk gf " d{ " o cpwxcwttgt" qt" ci gpw' Vj g" WRU" ku" f guki pgf " qpn{ " hqt" eqo o gtekrn' qt" kpf wutkrn'wug."pqv'cmqy gf "vq"r qy gt" hkg"uw r qtv'gs wkr o gpw'K'ku'y kj qw'y cttecpv{ "qh'vj g" f co ci g"ecwugf "d{ "f gtgi wrcv kqp0

P qvg<K'ku"uwdlgev"vq"o cng"ej cpi gu"vq"vj g"r tqf wev'f guetkdgf "kp"vj ku"o cpwcn'cv'cp{ "vko g" cpf " y kj qw" r tkqt" pqv'eg" hqt" tgc uqpu" qh' ko r tqxgo gpw' Rrgcug" eqpwcev" wu" hqt" rcvguv' kphqto cv kqp0

Content

Functions and characteristics	1
Safety instruction	2
Storage	3
Installation environment	3
Installation preparation	3
Connection	5
Startup process	6
Internal protection	6
Modes of operation	8
Technical Specification	11
Operation of Touch screen	13
Appendix	18
Parallel operation	19
Structure	20
dimension	21

Functions and characteristics

30Hwm'f ki kcn

Hwm'f ki kcn'vgej pqrmi { "dcugf "qp" f qwdrg" F UR "grko kpcvg" vj g" | gtq "f tkh" eqo o qpn { "d { cpcrmi . "o cng" k' gcu { "vq" vr f cvg" cpf "o c kpvpcpeg=" eqpxgpkgpv" vq" wug" o qf gtp" eqpvtqr o gyj qf u="cf xcpegf "rqi le" o cpci go gpv=" " r tqxf g" tlej "kpwgtcevkg" kpwgtceg

40Tgrkcdkkrv{

J ki j "tgrkcdkkrv{ "Vj { tkurqt" r j cug/eqpvtqmgf "tgevkhtgt. "K DV" o qf wr" dcugf "hwm/dtkf i g kpxgtvgt=" kpxgtvgt "kuqrkvp" vtcpuhqto gt="vj g" dcwgt { "ku'f kgevn{ "eqppgevgf "vq" F E "DWU. y j lej "cej kxgu" | gtq "vcpuhgt" vko g" htqo "wkrkv{ "vq" dcwgt { "UET" dcugf "ucvke" uy ke j cej kxgu" | gtq "vcpuhgt" vko g" htqo "kpxgtvgt" vq" d { r cuu" cpf "xleg" xgtuc

50Gzegngpv'kpr w'cpf "qwr w'ej ctcevtkruku

Kpr w' r qy gt" y cm/kp." dpgghk" vj g" eqppgevkqp" qh" i gpgtcvkqp" cpf " r qy gt" vtcpuhgt i gpgtcvqt" r qy gt" rko k' o qf g. "Y kf g" kpr w' xqnci g" tpci g. "eqo r rkp' vq" o quv' xqnci g ucpf ctf <5: 2X1622X1637X"72J | 182J | "Qwr w' RH2Q *rci =

4. Professional battery management (PBM)

Kpvgnki gpv'cwq" vtcpukvqp" dgvy ggp" gs wcrk kpi "ej cti g" cpf "hmqvki" "ej cti g=" Dcwgt { "dcemw" vko g" r tgf levkqp. "Rgtkqf le" ugrh/ vguv=" r gpi vj gp" dcwgt { "rkhg

70P - Z" r ctcngn' o qf g

Qpn { "eqppgev" vj g" r ctcngn' ecdrg" cpf "f q" uqo g" ugwkpi "ecp" cej kxg" vj g" r ctcngn' o qf g. vj g" o cuvg" "ecp" dg" ugv' cv" y km" y j gp" vj g" o cuvg" "hcwv" "qpg" qh" vj g" urxgu" y km' dg" o cuvg" cwqo cvcmk" "ecp" dg" eqppgevgf "kpr ctcngn' gki j v'wpku" o cz00

6. Load Bus Synchronization (LBU+

NDU" tgrk k gu" vj g" u { pej tqpk cvkqp" qh" vj g" vy q" u { uvg. "k" r tqxf gu" j ki j "tgrkcdkkrv{ "qh UVU" hqt" vj g" f wcr qy gt" uwr r n { "u { uvg

90Rgthgev' r tqvevkqp

Qxgt" xqnci g" r tqvevkqp. "qxgt" htgs wpe { "r tqvevkqp. "qxgt/ewttgpv' r tqvevkqp. "qxgt" dwi xqnci g" r tqvevkqp. " qxgt/ vgo r gtcwtg" r tqvevkqp. " cwzkrkt { " r qy gt" uwr r n { " hckwtg r tqvevkqp. " qwr w' qxgtmqf" r tqvevkqp. " qwr w' uj qt vektewk" r tqvevkqp. " go gti gpe { uj wf qy p

: 0Rgthgev' o qpkqt kpi

TU454" cpf "TU6: 7. "rci g/uetggp" NEF "r cpgr=" o qpkqt" ugevkqp" o qpkqtu" vj g" ucwv" qh" vj g" WRU. " " vtcpuhgtu" eqo o cpf. " " tgeqtf u hckwtg" gxgpv' k' vj g" j kvqt { "tgeqtf. "cpf "eqo o wplecvgu" y kj "j quv" " eqo r wgt

Safety instruction

This manual contains installation and operation, please keep it!

Vj gtg'ku'f cpi gtqwu'xqnci g'cpf "j ki j "vgo r gtcwtg'kpukf g'vj g'WRUOF wtłpi "vj g'kpucnc'vqap. qr gtcvqap"cpf "o cłpvqpcpeg. "r rncug"cdkf g'vj g'mqecn'uchgv{ "kpustwekqpu"cpf "tgrnc'xg"ncy u. qvj gty kug'kv'y kn'tguwn'kp"r gtuqppgn'kplwt { "qt"gs wkr o gpv'f co ci g0'Uchgv{ "kpustwekqpu"kp vj ku'o cpwnc'cev'cu'c"uwr r ngo gpvt { "hqt"vj g'mqecn'uchgv{ "kpustwekqpu0"

30 Vj gtg'ku'j ki j "rncnci g'ewttgpv'kpukf g. "uq"i tqwpf "hktuv'dghqtg"eqppgevkpi "vq"wkłkv{0

40 Vj qwi j "vj g'wkłkv{ "kup-÷"eqppgevgf "kp. "vj gtg'ku'vkm'CE"xqnci g'cv'qwr w."uq"r rncug qr gp'cm'vj g'uy kej gu'y kvj kp'vj g'ltqpvr'cpgn'y j gp'ew'qh'vj g'qwr w'qh'vj g'WRU0

50 Rncug'f qpø'qr gp'vj g'eqxgt"qh'vj g'WRU."vj gtg'ku'tkum'qh'grgevtke'uj qen0

60 Dcwtg { "tgr rncgo gpv'o wuv'dg"fgpg"d { "r tqhguukqpcr0'Vj g'kpukf g'qh'vj g'dcwtg { "o c { eqpvckp" vj g'vqzke" kpi tgf kpvu." uq" vj g"y cuvtg" dcwtgkgu" uj qwf "dg" ugpv' vq" ur gekr f gr ctvo gpv'hqt"cr r tqr tkvg"vtgcwo gpv'0F q"pqv'qr gp"qt"f co ci g'vj g'dcwtg {0'Vj g'uj qtv ekewk'ku'r tqj kłkvf. "qt"kv'o c { "ecwug"cp"gzr młkqp."hktg"cpf "eqttqkqp."y j kej "o c { "f q j cto "vq"vj g'r gtuqp0

70 Y j gp'tgr rncpi "vj g'hwug."r rncug"wug"vj g'hwug"qh'vj g'uco g'ur gekr hccvqap0

80 Cn'vj g'kpvtpcrlo cłpvqpcpeg"o wuv'dg"fgpg"d { "vj g'r tqhguukqpcr"vtckpvgf "r gtuqp0

90 Cn'vj g"eqo o wplecvkqp"rkgu"o wuv'wug"uj kgrf gf "ecdngu"vq"r tqvge'v'uki pcn'htqo "vj g'kpvtgthtqpeg0'kp"c"tgukf gpv'cn'gpxktqpo gpv."vj ku'r tqf wev'o c { "ecwug"tcf kq'kpvtgthtqpeg. vj gtghqtg"uqo g'cr r tqr tkvg"o gcuvtgu"o wuv'dg"vcngp0Hqt"gzco r ng."o qxg'vj g'WRU'hqt uqo g'f kvcpeg"vq'tgf weg"vj g'kpvtgthtqpeg0

Storage

Vj g'uvqtcı g'r ræg'o wuv'o ggv'vj g'hqmıy kpi 'tgs wktgo gpw<

Vgo r gtcwtg< 2 62 *54 326 +

Tgrvxg'j wo kf k< ; 7' "

Installation environment

Y j gp'ugrev'vj g'kpuvcvkvq'tqqo . 'r ræguc'veng'pqv'qh'vj g'hqmıy kpi <

30 Vj g'r ræg'o wuv'dg'ft { . 'engcp'cpf 'y gm'xgpvkvvgf 0

40 Ej gem'y j gvj gt 'vj g'hqmıy 'ku'utqpi 'gpqwi j 'vq'dgct 'vj g'y gli j v'qh'WRU'cpf 'dcwgt { 'dqz0

50 Ej gem'y j gvj gt 'vj g'tqqo 'ku'rtı g'gpqwi j 'hqt 'kpuvcvkvq'cpf 'o ckvpgpcpeg0

60 Y j gp'WRU'ku'twppkpi . 'ej gem'y j gvj gt 'vj g'co dkgpv'vgo r gtcwtg'ku'dgy ggp"2
62 0

70 Vj g'tgeqo o gpf gf 'vgo r gtcwtg'ku'dgy ggp"42 47 0'Vj g'qr gtcvki "rkg'qh'vj g
dcwgt { 'y knlf getgcugf 'f vq'v'vj g'kpetgcukpi 'vgo r gtcwtg0'Vj g'vgo r gtcwtg'tkugu"32 .
vj g'rkg'y knldg'j crf0

80 F qp'vr ræg'vj g'o cej kpg'f kgev< 'kp'uvpıki j v'qt'pgct 'vj g'j gcv'uqwtg0

Kp'qtf gt 'vq'o ggv'vj g'cdqvg'tgs wktgo gpw. 'k'ku'pgeguuct { 'vq'grko kpcv'vj g'j gcv'f kuuk cvgf
d { 'WRU.'vy q'o gvj qf u'ecp'dg'wugf <


P cwtcn'xgpvkvq'vkvq'

Hqtegf 'eqqrkpi '*ck'eqpf kvkqpgt'u{ uvgo +"


Installation preparation

30 Tgo qvg'vj g'r cenı kpi 'ectghmı { . 'f qp'v'f co ci g'vj g'qtkı kpcn'r cenı kpi . 'ej gem'kh'vj g
o cej kpg'ku'f co ci gf 'kp'vcpuk0'k'ku'hqwpf 'f co ci gf . 'r ræguc'f qp'v'uctv'vj g'o cej kpg
cpf 'pqvkh { 'vj g'ectlkt'cpf 'f gcrgt0

40 Ej gem'kh'vj g'gs vkr o gpv'ku'lvuv'vj g'tki j v'v{r g'q'w'qtf gtgf 0



Ræguc'ectt { 'k'kp'cp'cr r tqr tkvg'y c { "



Wpıqcf gf 'htqo 'vj g'r cmgv"

Placement

Y j gp'r rækpi "yj g'WRU."nggr "kp'o kpf "yj g'hqmqy kpi "r qkpw<



30 Ngcxg"cv'rgcuv'3o "qh'wpqdut wevgf "ur ceg'kp'htqpv'qh'yj g'o cej kpg'hqt"o ckwgpcpeg0

40 Ngcxg"cv'rgcuv'72eo "qh' wpqdut wevgf "ur ceg" cv' yj g" dcm' qh"o cej kpg" hqt" r tqr gtrf ' xgpvkrvgf 0

50 Ngcxg"cv'rgcuv'42eo "qh'wpqdut wevgf "ur ceg"dqvj "yj g"vy q"ukf gu"qh'yj g"o cej kpg"hqt o ckwgpcpeg0

60 F q'pqv'tguv'cp{ "qdlgev'qp'vqr "qh'yj g'WRU0

62M



Dqwqo "xkgy


Connection

Qpn("dqj "vj g"WRU"ku"fkueqppgevgf "htqo "vj g"wkxk{"cpf "vj g"uy kej "ku"qhh"ecp"vj g' eqppgevkp"dg'r gthqto gf 0Tgo qxg"vj g"uy kej "r cprf)

Vj g'ht uv'ugr <eqppge'vj g'i tqwpf 'y kt g'vq'vj g'i tqwpf kpi "dct

O CKP U'cpf "NQCF "EQP P GE VKQP "

32/: 2MXC*O CKP U'cpf "D[RCUU'kpg"VQI GVJ GT+ "




N3C.'N4C.'N5C.'P <o ckpu'kpr ww"
 N3D.'N4D.'N5D.'P <d { r cuu'kpr ww"
 NzC? NzD.'o ckpu'kpr ww'cpf "d { r cuu"
 kpr ww'j cxg"dgpp"eqppgevgf "

Hqt "kpr w'cpf "qwr w'y kt g'uk g.'r ngcug'tghgt "vq'vj g'vdmg"*o czko wo "uk g'kp"dtcengv+ "

	uk g(mm ²)		
	kpr ww	I tqwpf	Qwr ww
kVA	L1/L2/L3/N	PE	L1/L2/L3/N
40	25 (35)	25 (35)	25 (35)

32/: 2MXC"*o ckpu'cpf "d { r cuu'kpg'ugr ctcvg+ "



N3C.'N4C.'N5C.'P <o ckpu'kpr ww"
 N3D.'N4D.'N5D.'P <d { r cuu'kpr ww"
 Vj g'eqppgevkp"dgw ggp"NzC"cpf "
 NzD'j cu'dggp'tgo qxgf

Startup process

Chgt"eqo r rvg" vj g"eqppgevkqp" cpf "ej genkpi ." o cmg" uwtg" vj g" kpr w"uy ke j "qh" WRU" ku emugf 0'

Y ctpkpi < "

Vj gtg"o c { "dg"xqnci g'r tgugpv'cv'vj g"qwr w'f wtkpi "vj g" hmqy kpi "qr gtcvkp0'Rngcug"qr gp vj g"uy ke j "eqppgevgf "vq'vj g"mqf "kh'pgeguuct {0'

30 Emug"vj g"UY D["cpf "UY QWV"qh'vj g"WRU0

Vj g"NEF "dgi kpu"vq"twp0'Y j gp"vj g"WRU"uwtv. "k'y km'y qtn'kp"d { r cuu"o qf g"cv'htucl P qy . "vj g"ucwu"qh'rgf "kpf lecvtu"ku"cu" hmqy kpi <d { r cuu"rgf " *D[RCUU+"cpf "mqf "rgf *QWRWW+"rki j v'i tggp. "dcwgt { "rgf " *DCV0+"rki j w'tgf . "y ctpkpi "rgf " *UVCVWU+"rki j v' { gmjy 0

40 Emug"vj g"UY K

Vj g'tgevkgt"uwtv. "ku"rgf " *TGEVKHGT +"drkpm"kp"i tggp0'Cdqw"37"ugeqpf u'revt. "vj g'tgevkgt"dgi kpu"vq'y qtn'pqto cm{ . "cpf "vj g"i tggp"rgf "rki j w0

50 Ej gen'vj g"FE "dwa"xqnci g"cpf "r qmktk{ "qh'vj g"dcwgt { . "vj gp. "emug"vj g"gzvgtpcn'dcwgt { uy ke j 0

60 Y j gp" vj g"u{ ugo " f gvgeu" vj g" r tgugpeg" qh' vj g" dcwgt { . "vj g" tgf " dcwgt { " rgf " *DCV0+ gzvki wkuj gf 0

70 Ej gen'cpf "qr gp"vj g"kvgtpcn'o clvpcpeg"d { r cuu"uy ke j " *UY O D+

80 Rtgau"vj g"dwwqp"K XGTVGT"QP" cpf "j qrf "k'ht'cv'rgcu"4"ugeqpf u0

Vj g"kvgtvt"dgi kpu"vq"uwtv. "y j gp"kvgtvt"u{ pej tqpk gu"vq"d { r cuu. "vj g"kvgtvt"rgf " *K XGTVGT +"drkpm0'Y j gp"vj g"kvgtvt"uwtv. "WRU"tcpuht"vq"kvgtvt"o qf g"ltqo d { r cuu"o qf g0'P qy . "d { r cuu"rgf " *D[RCUU+"gzvki wkuj gf "cpf "vj g"kvgtvt"rgf "rki j v' i tggp0


90 O cmg"uwtg"vj cv'vj gtg"ku"pq"cmto "o guuci g"f kur r { u"kp"NEF "uetggp. "cpf "vj g"rgf "ucwu ku" cu" hmqy u< TGEVKHGT K XGTVGT IQWRWW" rki j v' i tggp. " vj g" qjgtu gzvki wkuj gf 0

Internal protection


Vj g"ur gekhcvkpu"cdqw"vj g"hwgu"cpf "uy ke j gu"kvcmgf "kp"vj g" kpr w"cpf "qwr w"rkpu ctg"cu" hmqy u. "c"hwg"o wuv'dg'tgr rnegf "qh'vj g"uco g"v{ r g0'

	O i ^ æ ^ i	Û , ã & @	Ø • ^
Σ X O Æ	UY Q	UY O Y	O æ i ^ A ^ • ^
I €	ì € OE HÚ Ô	î H OE HÚ	FI € O Æ Î € Q Æ Ü

MAINTENANCE BYPASS *O CP WCND[RC UU+



Uc wu'c'0'p'q'to c'n'q'r g'tc'v'k'q'p



Uc wu'd"

30 Rt guu'v'j g'dw wq p"\$K P X G T V G T"\$Q H H"q p"v'j g"eq p t q n'r c p g n'V'j g"l p x g t v g t"y k m'd g"q l h
c p f"v'j g"n q c f"y k m'd g"r q y g t g f" d { "d { r c u u'V'j g"l p x g t v g t" N G F"y k m'd g"q l h" c m't o "N G F
y k m'd g"q p 0


40 E m u g' u y k e j "U Y O D

V'j g"o c l p v g p c p e g" d { r c u u" k u' e q p p g e v g f" v q" v'j g" u c v l e" d { r c u u" l p" r c t c m g n' V'j g" q r g t c v k q p
o g u a c i' g' y k m'd g' u j q y" q p" v'j g" N E F 0

50 Q r g p' v'j g" q w r w' u y k e j " * U Y Q W W + " v'j g" n q c f" k u' h g f" f k t g e v l" d { "o c l p v g p c p e g" d { r c u u' K
k' k u' p g e g u a c t { " v q' w t p" q l h' t g e v k h k g t" c p f" d c w g t { . r n g c u g' i q" q p" v'j g" h q m q y k p i" u v g r u <

60 Rt guu'v'j g'dw wq p"öGRQö"q p"v'j g" h t q p v' r c p g n' h q t" c v' r g c u v' 4" u g e q p f u 0

K' y k m' w t p" q l h' v'j g" t g e v k h k g t . l p x g t v g t . u c v l e' u y k e j" c p f" d c w g t { " e q p w c e v t 0'



Uc wu'e" "


Q r g p' v'j g" k p r w' u y k e j " * U Y K P + " c p f" d { r c u u' u y k e j " * U Y D [+ " "

Y j g p" h k p k u j k p i" v'j g"o c l p v g p c p e g . " e m u g" v'j g" U Y K P . " U Y D [" c p f" " U Y Q W W" v q" t g u a c t v' v'j g
W R U 0'

R t g u u' v'j g" d w w q p" ö H C W N W " E N G C T ö" v q" g z k' " G R Q" e q o o c p f 0' V w t p" q l h' " U Y O D . " r t g u u' v'j g
ö K P X G T V G T " Q P ö" d w w q p" q p" v'j g" e q p t q n' r c p g n' h q t" o q t g" v'j c p" 4" u g e q p f u" v q" i g v' v'j g" W R U
d c e m' v q' p q t o c n' q r g t c v k q p 0'

Modes of operation

Drqemif kei tco



Rectifier

Represent the input stage, perform the AC/DC conversion, the functions are as follows:

1. Power the inverter with DC
2. Charge the battery automatically

External battery

When there is no power input, the battery provides power to load.

Inverter

Represent the output stage, convert the DC voltage from RECTIFIER or BATTERY to sine AC voltage.

Static switch

It is an automatic or manual switch. It is used to transfer from the inverter mode to bypass mode or vice versa.


Manual maintenance bypass switch (SWMB)

This switch is only for maintenance, when it closed, the load is directly powered by mains. With the SWMB closed and the other switches open, no voltage inside the equipment (voltages are present only at the input and output terminals and switches area).

Note: the neutral is not interrupted

LINE MODE

The mains power is present, the SWIN, SWBY, SWOUT are closed, the SWMB is open.



The load is powered by inverter. The rectifier converts the AC voltage to DC voltage to power inverter and charges the battery. The leds of RECTIFIER, INVERTER and OUTPUT are lit green.

Note: when the mains power failure, the load remains to be powered by UPS, using energy from the battery.

Load energy backfeed protection


If the load carried by the UPS output is a motor-type load, energy will be backfeed to power terminal when the motor is braking, the Crowbar-circuit which connected to the UPS bus will be activated in time to absorb the energy from the motor load, ensure UPS bus stability and battery life.

Technical Specification

Three-phase input three-phase output	
Rated capacity(VA)	40KAVA
Active power(W)	36KW
INPUT	
Voltage Range	380/400/415Vac (-25%~+20%) three phase
Frequency Range	50/60Hz±5Hz auto identification
Power Factor	>0.8(no filter) >0.9(with filter)
OUTPUT	
Voltage Range	380/400/415Vac ±1%
Rated output current	60A
Frequency	Auto learning
Frequency stability(battery mode)	50/60Hz±0.05%
Wave form	Sine wave
Power Factor	0.9(lag)
Total harmonic distortion	<3% (linear load) / <5%(nonlinear load)
Overload capacity	105%≤60min <110% / 110%≤10min<125%
Crest Factor	3: 1 (max)
Efficiency	90%
Transfer time	
Line mode? Battery mode	0ms
Bypass	
Rated voltage	380/400/415Vac (three phase four wire)
Voltage protection range	-40%~+20%
Rated frequency	50/60Hz
Frequency protection range	±20%
Transfer time	0ms/1ms
Overload capacity(In)	15In, 10ms 5In, 5s
Battery	
Voltage (VDC)	384VDC
Panel	
LED	input, inverter, bypass, battery and output
LCD	input and output voltage, frequency, power factor, battery voltage, battery current and status, load percentage, UPS status, history record, setting
Communication	
interface	Dry contact, RS232, RS485, SNMP card slot
Working environment	
Running Temperature	0~40℃
Relative humidity	0~95% (without condensing)
Storage temperature	-25℃~55℃
Noise at 1	<63dB
Optional	Harmonic Filter, SNMP adapter, Bypass current-sharing inductor

BATTERY MODE

Mains power is off, the SWIN, SWBY and SWOUT are closed, the SWMB is open.




If the mains power is off or out of range, battery discharges to provide power to load. The green led of BAT., INVERTER and OUTPUT on the front panel are on, STATUS is on, and the buzzer alarms.

Note:

When the battery voltage drops below the pre-alarm value, the led BAT. will blink, now, save the data under this condition. The battery will run out and UPS cuts off its power to load if mains power remains off.

BYPASS MODE

Mains power present, the SWIN, SWBY, SWOUT are closed, the SWMB is open.



If the inverter fails or over-load, and the inverter is synchronous with the bypass, the static switch will be activated, the inverter mode will be transferred to bypass mode without interruption. If asynchronous, the output will be interrupted when transfer. The led of the BYPASS and OUTPUT are on, STATUS led is on. The buzzer alarms.


Note: In case of over-load, reduce the load to the permitted range, then UPS will be back to inverter mode, otherwise, the load will not be protected by UPS.

Operation of Touch screen

This chapter offers a detailed introduction about the function and usage of the UPS Touch screen panel, and its display information, including detailed menu information and prompt window information, and UPS alarm message list.

Introduction

The touch screen, located at the front of the machine, is used to control the UPS and query all of its parameters, including battery status, event log and alarm messages. The display panel can be divided into five parts by function: system information, menu, main display area, status indicator and EPO button. The above parts of the panel and name is showed in Figure below.



UPS operation control touch screen

System Information

This part shows the logo, model, and capacity of the UPS.

Status indicator

There are 3 indicator lights in the status indicator area, which are used to show the working status of the UPS. The status meaning of each indicator light is described as shown in the following table.

LED	State	Mean
FAULT	Red	UPS Failed
	OFF	UPS no fault
ALARM	Yellow	UPS Alarm
	OFF	UPS no alarm
NORMAL	Green	UPS normal
	OFF	UPS failure or alarm

Buzzer alarm

When the UPS is running, three different sounds of alarm can be followed, which are described as shown in the following table.

A single short buzz of alarm	Press any function key to send the alarm
A buzz of alarm every other second	In case of UPS warnings (e.g. abnormality in the main path voltage), such alarm will be active
continuous buzz of alarm	In case of UPS failure (e.g. blown fuse of the main path or other hardware failures), such alarm will be active

Main display area

This part is the main display, the content varies depending on the menu.

Menu

The panel offers seven menu items. Function description of each item is showed in Table below.





N.O.	Menu	Description
1	Home	mimic operation diagram of UPS
2	Alarm	Display the faults of UPS
3	Status	Realtime status, history record, download
4	Settings	Settings for data & time, communication baud rate and address selection
5	Control	Operation of the UPS: UPS ON/OFF, fault alarm on/off etc.
6	About	Software version, manufacturer info

Touch screen interface is user-friendly. With the easy-to-use menu-driven operating system, it is convenient to get the parameters of input/output/load/battery status of the UPS and acquire the current status and alarm messages of the UPS timely, and conduct relevant function setup and control operations. Moreover, the panel can provide at most 10000 historical alarm records, which serve as a credible basis for fault diagnosis.

Detailed Menu

① Home

The Main menu offers the mimic operation diagram of UPS. The symbols SWIN(QF1), SWBY (QF2), SWMB(QF3), SWOUT(QF5) represents the mains input/bypass input/maintenance/output switch. The indicators shows the power path and status of UPS. The function description is showed in Table.

Name	icon	Status	Indication
Rectifier		Green on	Rectifier works normally
		Green flickers	AC is normal, but rectifier is not working
		Red on	Rectifier fault
		off	Rectifier does not work, mains input abnormal
Bypass		Green on	Load is powered by bypass input
		Red on	Bypass power supply is abnormal or beyond acceptable range; or fault of bypass switch
		off	Bypass normal, but does not power the load
Battery		Green	The battery is normal
		Yellow	Pre-alarm end of battery discharge
		Red	Abnormality occurs to the battery (battery fault, no battery or reversed battery connection) or the battery switch
Inverter		Green on	Inverter provides the load with power supply
		Green flickers	Inverter starts up, operates, synchronizes, or is in the stand-by state (ECO mode)
		Red on	Inverter fault
		off	Inverter out of work

②Alarm

There are three submenus: Real, Record, Export. It is showed as table below.

NO.	items	content	description
1	Current	real-time status	the real-time status of UPS
2	History	history record	history record of the UPS

③Status

The status menu displays the UPS operation data. The main display area shows the content according to the selected submenu on the left column. Through the menu, users can get relevant UPS parameters. Detailed description is shown in Table below.

NO.	submenu	items	description	
1	Mains	Line Voltage(V)	Mains input line to line voltage	
		Phase Current(A)	Mains input phase current	
		Phase Frequency(Hz)	Mains input frequency	
2	Bypass	Phase Voltage(V)	Bypass input phase voltage	
		Phase Current(A)	Bypass input frequency	
		Line Voltage(V)	Bypass input line to line voltage	
3	Output	Phase Voltage(V)	Output phase voltage	
		Phase Current(A)	Output phase current	
		Phase Current(A)	Output frequency	
		Line voltage(V)	Output line to line voltage	
		Power Factor	Power factor of load	
4	Load	Apparent Power(kVA)	Apparent power	
		Active Power(kW)	Active power	
		Reactive Power(kVar)	Reactive power	
		Load(%)	Percentage of UPS rated load	
		Peak Ratio	Crest factor of the output current	
5	Parallel	Apparent Power(kVA)	Apparent power	Available for parallel configuration, none for single mode
		Active Power(kW)	Active power	
		Reactive Power(kVar)	Reactive power	
6	Battery	Voltage(V)	Bus voltage of the battery	
		Current(A)	Bus current of the battery	
		Temperature(°C)	temperature of the battery group(0)	
		Remaining Time(Minute)	The remaining working time of the battery	
		Charging Status	Battery boost charging/Battery float charging/Not charging	

④Settings

The item is for UPS parameters settings. Including the Time, Address, Language. Detailed description is shown in Table.

NO.	items	content	description
1	General	Date & Time	Date and time settings Year-month-day-hour-minute-second
		Change Password	Change password
		Screen Calibration	Screen Calibration
2	Communication	UPS Address	Address for UPS communication
		RS232 Baud	9600/4800/2400 settable
		RS485 Baud	9600/4800/2400 settable
3	Log	Reset Log / Export Log	Reset Log / Export Log
4	Language	Chinese / English	touch screen display language
Users can enter this menu only with the correct password. The initial password is 9662			

⑤Control

ON/OFF, Common, Command are sub items of the Control menu. Detailed description is shown in Table.

NO.	items	content	description
1	INV ON/OFF	Power On	Press the button to start the inverter
		Power Off	Press the key to shut off the inverter. UPS will go to bypass mode if on inverter mode
2	SELF-TEST	Maintenance Test	Manually start the battery maintenance test. In the process, the battery will partially discharge for a rough evaluation of the battery capacity. To meet the test requirements, the load must be between 20% and 80%; and the battery must have just been in the course of a floating charge for more than 5 minutes continuously.
		System Test	Manually start the system test (i.e. UPS self-detection). After the system test proceeds for about 5 seconds, a window will be popped up on the screen to show the test result: No faults detected, Fault Clear Alarm.
		Stop Test	Manually stop the battery maintenance test, battery capacity test or system test.
		Force Boost Charging	When the battery is not in the course of equalizing charge, manually initiate a forced equalizing charge for the battery.
		Stop Boost Charging	Manually stop a forced equalizing charge for the battery.
3	GENERAL	Fault Clear	In case that UPS is off because of failure and alarm conditions are removed, press this button to clear the fault.
		Buzzer Toggle	When an alarm is activated, press this button once for silence of the alarm buzzer. If a new fault occurs, the buzzer will start an alarm once again. In case that the buzzer fails to give an alarm, press this button to test the sounds of alarm.

⑥About


This menu offers HMI Version, Vendor, Monitor/Rectifier/Inverter version information.

EPO button


When the UPS is running, three different sounds of alarm can be followed, which are described as shown in the following table.

Appendix

Parallel operation




parallel connection diagram



input and output cable connection diagram

the length of the input and output wire is nearly the same, for example:
 $A1=a2=a3, c1=c2=c3$ or $a1+c1=a2+c2=a3+c3$




parallel connection diagram

The two parallel cables from the parallel boards X1-1 and X2-2 of one UPS are respectively connected to the parallel boards X1-2 and X2-1 of the next UPS.

Appendix

Structure


10-40KVA



Appendix

Structure

60-80KVA





POWER SOLID

WWW.POWERSOLID.VN